

GM No Drill Kit AO46

This No Drill Kit is used in place of the 2 standard end plates included with the AO50 Cody Hitch. Mounting hardware included with the standard end plates will be used with this no drill kit and is included in this parts list.

| Quantity | Part | Use |
|----------|-----------------------------|--|
| 2 | Clamp Plate | End plate to secure hitch |
| 2 | Clamp Bars | Secure front of Clamp Plates to truck frame |
| 4 | 4 1/2"x 1/2" Grade 8 bolts | Secure Clamp Bars to Clamp Plates |
| 2 | 1/2" Wide area flat washers | Secure Clamp Bars to Clamp Plate /lower slotted U-bolt holes |
| 2 | 1 1/2" x 1/2" Grade 8 bolts | Secure rear of Clamp Plates to truck frame |
| 2 | 1/2" Heavy flat washers | Secure rear of Clamp Plates to truck frame |
| 6 | 1/2" Top lock nuts | Clamp Bars & rear bolts |
| 1 | Angle Bracket | To relocate Electric Brake Controller from drivers side rear mounting hole |

Brake Controller Mounting Angle Bracket

